


Washing and Drying Cycle Guide



Washstation
Smart. Green. Clean.

Wash wisely

Washer

Always check the label on your clothes!



Whites
(Hot wash)
60 c / 140 f
Whites / Bedding




Colours
(Warm wash)
40 c / 104 f
Darker t-shirts, underwear,
jeans and jumpers



Bright colours
(Warm wash)
40 c / 104 f
Brighter t-shirts, underwear,
jeans and jumpers

RECOMMENDED
CYCLE



Perm press
(Warm wash)
40 c / 104 f
Low spin for items with
a permanent crease
(permanent press)

NOT FOR
GENERAL LAUNDRY



Woollens
(Cold wash)
30 c / 86 f
Very slow spin

NOT FOR
GENERAL LAUNDRY




Delicates
(Cold wash)
30 c / 86 f
Very slow spin speed and
reduced wash action

NOT FOR
GENERAL LAUNDRY

Dryer

Always check the label on your clothes!



Whites / Colours
Cottons, denim, towels
and bedding

RECOMMENDED
CYCLE

Perm press
Uniforms and other clothes
for ironing

WILL LEAVE
CLOTHES DAMP

Delicates
Light, delicate garments

WILL LEAVE
CLOTHES DAMP



Scan here for Espanol, Francais,
Cymreig, 中文 version

Washstation Helpline 0800 141 2331
service@washstation.co.uk