


# Washing and Drying Cycle Guides



Washstation  
Smart. Green. Clean.

Wash wisely


## Washer

Always check the label on your clothes!

Eco Standard cycles

Superwash 3 mins extra on main wash

Superwash plus 2 mins extra on main wash & 1 extra rinse



Whites


(Hot wash)  
60 c / 140 f  
Whites / Bedding



Colours


(Warm wash)  
40 c / 104 f  
Darker t-shirts, underwear,  
jeans and jumpers

RECOMMENDED  
CYCLE



Bright colours

(Warm wash)  
40 c / 104 f  
Brighter t-shirts, underwear,  
jeans and jumpers



Perm press

(Warm wash)  
40 c / 104 f  
Low spin for items with  
a permanent crease  
(permanent press)


NOT FOR  
GENERAL LAUNDRY



Woollens

(Cold wash)  
30 c / 86 f  
Very slow spin

NOT FOR  
GENERAL LAUNDRY




Delicates

(Cold wash)  
30 c / 86 f  
Very slow spin speed and  
reduced wash action

NOT FOR  
GENERAL LAUNDRY

## Dryer

Always check the label on your clothes!



Whites / Colours

Cottons, denim, towels  
and bedding

RECOMMENDED  
CYCLE

Perm press

Uniforms and other clothes  
for ironing

WILL LEAVE  
CLOTHES DAMP

Delicates

Light, delicate garments

WILL LEAVE  
CLOTHES DAMP



Scan here for Espanol, Francais,  
Cymreig, 中文 version

Washstation Helpline 0800 141 2331  
[service@washstation.co.uk](mailto:service@washstation.co.uk)